

Radar separation

General

Radar separation describes a minimum horizontal and vertical distance that must exist between two aircraft in the air.

As safety is the greatest asset in aviation, care must always be taken to ensure that separation is maintained at all times.

Radar separation is **maintained** when between two aircraft **either** the horizontal distance **or** the vertical distance exists (or of course both).

When two aircraft have **neither** the minimum horizontal **nor** the vertical distance, this is called a **loss of separation (LoS)**. A loss of separation caused by the controller will always result in a failure in the exam.

Radar separation is used wherever air traffic control has radar equipment available to check separation. In Germany, all Approach and Center stations have this equipment and so radar separation is used throughout Germany. The tower controllers at international airports (EDDx) also have a radar screen for separation, so radar separation must also be ensured in the tower area for approaches and departures.

There is a [separate guide](#) detailing radar separation explicitly for **tower controllers**.

Need for separation

Whether two aircraft must be radar-separated depends on the respective airspace and the applicable flight rules.

The following table provides an overview of the separation obligation:

		controlled			uncontrolled
		C	D	E	G
IFR	separation	to IFR/VFR	to IFR/SVFR*	to IFR	procedural
	traffic info	not req	VFR	VFR if poss	if poss
	speed limit	M.99	250 kts	250 kts	250 kts
	on freq	mandatory	mandatory	mandatory	recommended
	clearance	required	required	required	not req
VFR	separation	to IFR	SVFR* to IFR	none	none
	traffic info	VFR	IFR/VFR	if poss	if poss
	speed limit	250 kts below FL100	250 kts	250 kts	250 kts
	on freq	mandatory	mandatory	nighttime	nighttime
	clearance	required	required	not req	not req

*) SVFR in CTRs only

In other words, there is obligatory radar separation between:

- (all flights in airspace A and B - does not exist in Germany)
- IFR to IFR in airspace C, D and E
- IFR to VFR and vice versa in airspace C
- Special VFR to IFR in the control zone

Vertical separation

The following vertical separation must be applied between two aircraft subject to separation:

Level	Vertical separation	Remarks
FL410 - UNL	2000 FT	
FL290 - FL410	2000 FT	during CVSM (exception)
	1000 FT	during RVSM (standard)
GND - FL245	1000 FT	

This regulation applies to aircraft flying at altitudes as well as at flight levels. Important further information can be found in the corresponding [altimetry article](#).

Vertical separation must not be used on **final approach**, horizontal separation only is applied here.

Horizontal separation

The following horizontal separation must be applied between two aircraft subject to separation:

Level	Horizontal separation	Remarks	
FL245 - UNL	5 NM		
GND - FL245	3 NM		
Final approach within 10 NM	2,5 NM	ONLY if specified and approved by SOPs!	

The horizontal separation is always measured as a direct line **between centers of targets**.

Formation flights must be separated to other traffic with **1 NM** more than the required minimum distance.

Two formation flights must be separated with **2 NM** more than the required minimum distance to each other.

If the required **wake turbulence separation** is higher than the above values, it must be given priority, so that the higher value always applies.

Revision #4

Created 13 September 2024 11:23:12 by 1583954

Updated 1 October 2024 20:48:11 by 1583954