


vACDM Pilot Guide

vACDM is short for virtual **Airport Collaborative Decision Making**. It is a concept that ensures minimal delays and optimal efficiency by making operations more predictable for all parties involved. There are over 50 airports that implement ACDM procedures in the real world, with over 30 of them located in Europe.

It works by allotting departure times to all departing aircraft, taking the airport's current capacity into account, which are calculated backwards to times for pushback and startup approvals. Since it would be impossible to plan everything down to the minute, there are always timeframes around the exact times you are given in the ACDM procedures during which the time is valid. We will go into this a bit further below.

How does vACDM work?

The system behind ACDM is very complex and it is not necessary for you as the pilot to understand it in every detail. Due to some simulator and network limitations, vACDM also can't simulate every aspect of its real world counterpart, mainly prohibiting network-wide flow management.



ACDM times

There are many different times used in ACDM procedures. However, we will only list the ones that are relevant for you as the pilot here. Keep in mind that **all times are given in UTC**.

Time	Name	Time Frame
------	------	------------

EOBT	estimated off-block time	±5 minutes
TOBT	target off-block time	±5 minutes
TSAT	target startup approval time	±5 minutes
CTOT	calculated takeoff time	-5 minutes / +10 minutes

EOBT (Estimated Off-Block Time)

This is the time **when you estimate to be ready for pushback during the creation of your flight plan**. ATC will use it as an initial, but unconfirmed indication of when you are going to be ready.

When prefilling from SimBrief, an EOBT will automatically be added to your flight plan. This time will be calculated based on when you start creating your SimBrief flight plan + 30 minutes. If you plan to depart earlier or later, it is recommended to change this time.

TOBT (Target Off-Block Time)

During the preparation of the aircraft, you might realize that you will be ready earlier or later than your original estimate. Keeping your TOBT up to date will help ATC to reduce delays and ensure a smooth operation. When you set a TOBT, ATC will treat it as a confirmed time and calculate your TSAT based on it. If you realize during any part of your preparation that a **new estimate will differ more than 5 minutes from the previous one**, you should set a new TOBT.

To set your TOBT, **we recommend using the vACDM pilot interface, which allows you to set it on your own**. If you did not set a TOBT yourself already, ATC will have to ask you to report your TOBT, which will lead to unnecessary frequency congestion.

It is generally good practice to **set your initial TOBT 20-30 minutes in advance and request enroute clearance 10-15 minutes before your TOBT** to ensure the information is available for ATC planning and that the controller can inform you of any potential delays or slot restrictions ahead of time.

If you do not set a TOBT, ATC might not be able to approve your startup right away when you are ready. Especially during periods of high traffic, **not setting a TOBT ahead of time can result in delays for you**.

TSAT (Target Startup Approval Time)

This is the time when ATC is planning to approve your startup. Keep in mind that it is ultimately **your responsibility as the pilot to request startup within the TSAT window; don't rely on**

the controller to call you for your startup. You can always find your current TSAT on the virtual VDGS in the [vACDM pilot interface](#).

In an optimal situation, your TOBT and TSAT will be at the same time. However, if there are more aircraft wanting to depart than the airport can currently accommodate, startups will be delayed and your TSAT will be at a later time than your TOBT.

If you **miss your TSAT window ($TSAT \pm 5$ minutes)**, the gap for departure is lost and a new TSAT has to be generated. Be aware that your **TSAT can improve** (and occasionally also worsen) depending on the general traffic situation and other aircraft's TOBTs.

Pushback needs to be **requested within 5 minutes of your startup approval**. At taxi-out positions you have **10 minutes to call for taxi**. After that time the startup approval is invalid and you will be told to recontact Delivery, who has to generate a new TSAT.

CTOT (Calculated Take-Off Time)

This is the actual slot. On VATSIM, you will usually not be issued a CTOT, so it is not a big deal to depart a little bit later or earlier than what ATC had originally planned. However, **during some busy events with slot bookings or if there are flow measures in place for your route, you will be given a compulsory CTOT** and have to depart in this CTOT window (CTOT - 5/+10 minutes). When you are given a CTOT, it is very important to meet it as another slot might not be available for over an hour.

How do I use the vACDM pilot interface?

To access the [vACDM pilot interface](#), you need to log in using your VATSIM account. The system will then search for your flight in the vACDM database.



Setting your TOBT

Next to the virtual VDGS, you can update your TOBT based on your current estimates. It has to be entered in UTC.

Set TOBT (UTC-Time when ready for pushback)

HHMM

Submit TOBT

Your TOBT (Target Off-Block Time) is the time you are fully ready for pushback. The initial TOBT you see here is the one extracted from your flight plan on VATSIM. Once you "confirm" or "update" your TOBT in the field above, ATC is able to better plan a departure sequence.

Once you have set your TOBT, it will show as confirmed. We ask pilots to **confirm their TOBT at least once** and **update it every time it changes by more than 5 minutes**.

Your TOBT is confirmed!

Set TOBT (UTC-Time when ready for pushback)

HHMM

Submit TOBT

Your TOBT (Target Off-Block Time) is the time you are fully ready for pushback. The initial TOBT you see here is the one extracted from your flight plan on VATSIM. Once you "confirm" or "update" your TOBT in the field above, ATC is able to better plan a departure sequence.

Virtual VDGS

Once your flight is logged in the vACDM process, you will see the virtual VDGS with your flight's current departure information.



- YOUR CALLSIGN
- CURRENT TOBT
- CURRENT TSAT
- time to go to (-) or elapsed since (+) your TSAT
- DEPARTURE RUNWAY
- PLANNED SID

Keep in mind that the departure information on the virtual VDGS will only be correct **once you have set a TOBT and have received your enroute clearance.**

Where is vACDM used?

vACDM is **currently in beta testing**, so it will only be available at a limited number of airports.

Keep in mind that not all controllers might be using this system yet. If you are unsure whether a controller is working with vACDM, **don't be afraid to ask them** - when the system is in use, it will usually be **announced in the ATIS**.

Revision #28

Created 3 April 2023 12:20:46 by 1627359

Updated 26 October 2024 21:59:40 by 1627359