

Tower


Münster Tower is responsible for the runway and traffic within the D control zone.

Runway in use: Runway 25 is used up to a tailwind component of 5 KT.

Approaches: For both runways ILS (25 CAT III, 07 CAT I), RNAV and NDB approaches are available.

Control Zone

The control zone of Münster/Osnabrück reaches from ground up to 2500 ft AMSL.



Münster/Osnabrück Control Zone (D-CTR) - © openflightmaps.org

VRP: The following visual reporting points are available at Münster.

VRP	Entry / Exit
D	exit rwy 25
N1 - N2	both
T	exit rwy 07 + entry
E	both
S	both

w	both
---	------

Special: **All VFR routes**, leading into or out of the control zone via the VRPs, have a **maximum altitude of 2.000ft MSL**. Overflights of villages Ladbergen and Greven shall be avoided, as far as possible. Corresponding information can be found on the Navigraph VFR chart or the VFR AIP, of the DFS.

TMZ: Outside the control zone is a TMZ where all VFR aircraft must set transponder code 6104.

Helicopter: The helipad for Christoph Westfalen is located south of the airport between the runway and the highway. There is no clearance required for take-off and landing, but for entering and leaving the CTR.



can use the bypass area at
C.

Bypass Area at each runway

end

Grass Runway: North of the runway paved runway, there is the grass runway of the "Luftfahrtvereinigung". Due to historical reasons, pilots can depart at this runway on own discretion, like at small airfields with information service. Parallel landings and take-offs are possible, and traffic information should be provided! Nevertheless, this traffic is controlled inside the control zone.

“ **Pilot:** DEABC, C172, nördliche Abstellfläche, VFR über S, erbitte Rollen, Abflug über Gras.

ATC: DEABC melden Sie abflugbereit Piste 25 Gras, QNH 1014.

“ **ATC:** DEABC, Verkehr Boeing 737 im kurzen Endanflug Piste 25, fliegen sie in die rechte Platzrunde Piste 25, Wind 230 Grad mit 5 Knoten, Start nach eigenem Ermessen.

Reduced runway separation

RRS minima may be applied by Münster Tower, according to the following table:

Runway	preceding CAT 1/CAT 2 succeeding CAT 1	preceding CAT 1/CAT 2 succeeding CAT 2	preceding CAT 3 succeeding CAT 1/CAT 2/CAT 3
07/25	600m	1500m	N/A

Auto-Handoff

Münster/Osnabrück utilizes an auto-handoff procedure for IFR departures, where **Tower will not hand off outbounds to the approach/center controller**. Make sure to set the correct departure frequency in the ATIS.

Outbounds should contact APP/CTR **immediately when airborne** unless explicitly told to remain on Tower frequency.

Revision #10

Created 6 October 2022 15:45:42 by 1288197

Updated 13 May 2025 20:57:31 by 1407054